



## ROCKGUARD® SD INSTALLATION GUIDELINES

### INSTALLATION GUIDELINES

ROCKGUARD® SD can be installed along the pipe or around the pipe as per the diagrams below and can be secured by means of polyester filament tape.

#### **PADS:**

1. Custom cut pads should be wrapped around the circumference of the pipe, covering all exposed areas. Ensure that all pads are of sufficient dimension to protect the entire pipe.
2. All pad overlaps shall be placed at the 6 o'clock position of the pipe, taking care to secure the ROCKGUARD® SD with a polyester filament tape.
3. Place all end to end overlaps min. 2"; all parallel pad overlaps minimum 6".
4. All pads shall be secured to pipe by using a min. 3/4" wide polyester filament tape.
5. After pads are secured to pipe, the backfill process may take place.

#### **ROLLS:**

1. All rolls should be of adequate coverage to entirely cover the circumference of the pipe.
2. ROCKGUARD® SD is to be placed around pipe, whereby placing overlap portion at the 6 o'clock position of the pipe.
3. Place all end to end overlaps min. 2"; all parallel pad overlaps minimum 6".
4. In the event that a side overlap is used place the overlaps "shingle style". This will ensure that no backfill will protrude under the ROCKGUARD® SD.
5. All rolls shall be secured to pipe by using a min. 3/4" wide polyester filament tape.
6. After rolls are secured to pipe, the backfill process may take place.

